



SGP Series Fully Pneumatic Piston Filling Machine



ATTENTION:

Machine must be completely torn down, cleaned, sanitized, and lubricated with H3 food grade lubricant prior to use. A recommended lubricant has been provided.

This machine requires an air compressor.

We would recommend a 20+ gallon compressor.

The air requirements for this machine are 5cfm@90psi.

866-888-6327

sales@clevelandequipment.com

4403 Delp Street

Memphis, TN 38118

www.clevelandequipment.com



Contents

Chapter 1 Overview	3
1-1 Overview	3
1-2 Features	3
1-3 Parameters	3
1-4 Working Principle	3
1-5 Working Process	4
1-6 Available Range	4
1-7 Introduction to Parts and Specifications	5
Chapter 2 Operation Instruction	6
2-1 Preparation	6
2-2 Operation Method	7
2-3 Fault Analysis and Troubleshooting	8
Chapter 3 Machine Set Up	10
3-1 Set-up	10
3-2 S Series Rotary Breakdown	15
3-3 Cylinder Breakdown	23
3-4 How to Rebuild the Rotary	28
Chapter 4 Machine Specifics – O Ring Seals	34
4-1 O-ring List	34
4-2 Seal Breakdown	35



Chapter 1 Overview

1-1 Overview

The SGP series fully pneumatic filling machines are newly designed for liquid, paste, and cream filling. Its filling amount can be adjusted as required based on the specified range, featuring high stability, reliability and filling accuracy.

1-2 Features

1. All surface materials of this machine are crafted of 316 stainless steel, which features high acid-resistance and corrosion-resistance properties, as well as presenting a high quality finish.
2. You can operate it safely and easily. Adjusting the filling amount can be performed within the range, as required, with high accuracy.
3. Its reasonable layout enables you to easily disassemble, safely operate, and easily clean the filler.
4. Due to a lack of electrical components, this filler can be used safely in a wide array of hazardous or moist environments.

1-3 Parameters

Item		SGP-60	SGP-120	SGP-250	SGP-500	SGP-1000
Available range		Cream/Liquid/Paste				
Filling range	Cream	5-60ml	10-120ml	25-250ml	50-500ml	120-1000ml
	Liquid	-	-	-	-	-
Filling accuracy	Cream	±2%	±2%	±2%	±2%	±2%
	Liquid	±1%	±1%	±1%	±1%	±1%
Working air pressure		0.4-0.5MPa				
Throughput		0-50 bottle/minute	0-30 bottle/minute	0-50 bottle/minute	0-40 bottle/minute	0-30 bottle/minute
Outline (length x width x height)		50x30x28 inches				
Net weight		83 lbs.				

Note: For this series of machine, the maximum liquid amount to be filled should be less than 5%-10% of the cream amount.

1-4 Working Principle

The cylinder runs in reciprocating and linear manners to drive the piston, thus generating suction and thrust to draw and push your product.



1-5 Working Process


Open the inlet valve, adjust the working air pressure and select the working status (automatic or semiautomatic). During the operation, the rotary cylinder linkage is turned (opens a path towards the front while sealing towards the top), the fill head cylinder moves upwards to open the discharge valve, the piston cylinder actuates to move the piston forward, which dispenses material for filling (the speed can be adjusted by the “Behind” valve); after that, the fill head cylinder moves downwards to close the discharge valve to prevent dripping, the rotary cylinder linkage returns (seals towards the front while opening a path towards the top), the piston cylinder actuates to move the piston rearward, which pulls new product into the chamber for the next filling (speed can be adjusted by the “Front” valve).

1-6 Available Range

It is ideal for special industries such as food, chemistry, pesticide and medication.



1-7 Introduction to Parts and Specifications



1. Hopper
2. Rotary assembly
3. Adjustable lock handle/sensor
4. Protective covering
5. Crossmember Bearing # 2OUU
6. Rotating hand wheel
7. Foot switch
8. Air regulator
9. Air gauge
10. Behind valve
11. Front valve
12. Product Chamber
13. Automatic/Semiautomatic switch
14. Under-chassis
15. Rotary air cylinder Air Tac MBC 25x75 CA
16. Fill head nozzle
17. Fill head cylinder



Chapter 2 Operation Instruction

2-1 Preparation

1. Precautions

- (1) The inlet air pressure should be 0.5-0.8Mpa and the working air pressure should be 0.4-0.5 Mpa.
- (2) Keep all appendages clear of moving parts during operation.

2. Filling amount troubleshooting

Adjust the filling amount as follows:

- (1) Put materials to be filled into the container.
- (2) Prepare measuring cup or scale to identify quantities desired.
- (3) Turn the hand wheel to adjust the variable sensor to desired range.
- (4) Check to ensure that the operation switch is set to semi-automatic, use the foot pedal to control the cycle, measure the obtained product to see whether it is in the desired quantity. If not, proceed by the following:
 - A Loosen the locking handle on the adjustable sensor.
 - B Turn the hand wheel clockwise or counterclockwise.
 - C Repeat step 4, using a measuring cup or bottle to measure the materials and adjust the handwheel until the obtained result is within the desired range.
 - D Tighten the locking handle on the adjustment sensor to avoid parts shifting and influencing the filling accuracy.



2-2 Operation Method

- (1) Connect the air source and slide the air inlet collar towards the machine.
- (2) Check whether the air pressure meter is in the specified range (roughly reading in the “12-3 o’clock” range). If not, draw the air pressure knob outwards to unlock, rotate the pressure regulator until the pressure is in the specified range (0.4-0.5Mpa) and push the knob back in to lock.
- (3) Use the Auto/Semiauto switch to set the filler to the desired operation method.
- (4) To make an adjustment, you can loosen the locking handle on the adjustment sensor, rotate the handwheel, take note of the value on the position display and fasten the handle.
- (5) Adjust the front valve (for adjusting drawing speed) and behind valve (for adjusting filling speed) as shown in Figure 1 to get reasonable drawing and filling speed.




Figure 1

- (6) Fill the hopper with product and prepare the container to be filled.
- (7) Proceed with filling and control the operation with the foot pedal. Step on the foot pedal once to finish each filling operation. You can adjust and use the Automatic function if you are proficient enough to keep up with the filling speed.



2-3 Fault Analysis and Troubleshooting

Symptom	Analysis	Troubleshooting
The machine fails	Check whether the air pressure collar is open	Open it
	Check whether the air source is open (compressor)	Open it
	Check whether the value on air pressure meter is within the correct range	Adjust it to 0.4-0.5MPa
	Check whether there is leakage on the pipe joint or damage on air lines	Insert the pipe again or replace
	Check whether the air amount is adjusted to the minimum (tightened too much) via the front valve and behind valve	Adjust the valves to the working status
	Check whether the air amount on the fill head cylinder is adjusted to the minimum (tightened too far)	Adjust the throttle to the working status
	Check cleanliness of the machine. Product may be hardened, tacky, or sticky, causing rotary assemble or main piston to be stuck	Clean the machine
Filling is not even	Check for air leakage in all air line connections.	Fasten each joint
	Check for leakage in the product chamber	Replace o-rings
	Check product level inside hopper	Add product
	Check for correct speeds during filling and drawing actions	Adjust the front valve and behind valve to the stable status
	Check whether the material viscosity is even	Make materials be even



2-4 Safety Instruction

You can use soap and warm water to clean the machine. Fill hopper with cleaning agent and water; cycle until discharge is clear of any product; fill hopper with clean water and cycle until water is clear.

1. Do not use sharp tools on surface when cleaning the internal parts. Install the parts when they are dry.
2. Use lubricant for all moving parts.
3. Check the o-rings of all parts and replace damaged rings.
4. Check whether there is damage or leakage on the air lines.
5. Fasten screws of all parts.
6. Never clean the filler via harsh or abrasive cleaners to protect the machines integrity.
7. Never cycle the filler without a product.
8. Never put hard materials into the hopper.
9. Filler should be on a flat surface in a dry place with little dust and enough room for movement during each filling cycle.
10. Use the machine in air-current environment when volatile liquid is to be filled.
11. Body or materials should be far away from moving parts and Cleveland Equipment takes no responsibility for any machinery and human injury due to negligence.
12. Cut off the air source when repairing or replacing parts and when cleaning.
13. Never use organic flux to clean the machine, such as gasoline, benzene, xylene, banana oil and sodium hypochlorite.




Chapter 3 Machine Set Up

3-1 Set-up

- Remove filler from packaging o Use caution – machine is heavy
- Situate filler on an even, stable surface
- Attach hopper using supplied stainless clamps o Make sure silicone gasket is seated correctly between flanges



- Attach fill head(s) if not already attached o Blue air line attaches to lower push-in fitting, black attaches to upper o Make sure silicone gasket is seated correctly between flanges





- Ensure that Auto/Semiauto switch is set to Semiauto



- Pull blue air inlet collar away from machine



- Attach air line from compressor, using either 8mm tubing or replacing the push-in fitting with a coupler-style quick-connect





- Push blue air inlet collar towards machine, allowing air to pressurize the system o At this point, you will hear a hiss as air enters the machine.
 - o The rotary air cylinder/fill head/main air cylinder may shift into position when the system pressurizes.



- The machine is now in the “resting position” and is ready to operate. The shaft inside the fill head should be down, the rotary assembly should be open to the hopper, and the main piston should be situated all the way to the rear, so that the crossmember is in contact with the rear sensor.



- Your machine comes set up to run. There are adjustable air fittings on the main air pistons, and also on the small air pistons that actuate the rotary cores. o The adjustable air fittings on the rotary core air cylinders are set to an optimal speed. If they run too slowly, your product won't dispense properly and may feed back into the hopper. If they run too quickly, the stainless bracket which clamps onto the end of the rotary core arm may over-rotate, moving your cores out of alignment



- The adjustable air fittings for the main air piston are set to an optimal speed as well. The “Front valve” controls how quickly the product will be dispensed from the nozzle. The “Behind valve” controls how quickly the product is drawn into the product chamber.



- The air gauge reads the overall air pressure coming into your filler. It should show a reading between the 1 o’clock and 2 o’clock positions. If it reads higher or lower, adjust the air pressure using the air regulator. Pull out on the knob to unlock it, then turn right to increase pressure or left to decrease pressure.






- The volume adjustment wheel on the rear of the machine has a numbered counter. This counter does not have a correlation to the actual volume of product being dispensed, i.e., “0201” does not mean 201 mL. We suggest that when you adjust the filler to the desired fill volume, make a note of the counter reading. In this way, if the filler is tampered with or you must change to another volume then back to the original, you can have an idea of the range you need to readjust to. Fine tuning will be necessary to return to the exact desired amount.








3-2 S Series Rotary Breakdown

How to break down the rotary














The arrow points to the large bearing inside the rotary, check this and the other side to find the smaller of the two. You will then drive the shaft toward the smaller bearing, Being careful not to drop the rotary core when it comes out and to use the correct tools. All will be demonstrated in the next few steps.

















3-3 Cylinder Breakdown



Cylinder removal and piston check. To put the cylinder back together, please reverse these steps.




Cylinder removal and piston check
to put the cylinder back together please reverse these steps

















3-4 How to Rebuild the Rotary















Chapter 4 Machine Specifics – O Ring Seals

4-1 O-ring List

Machine comes standard with Buna O-rings

Piston: 4x16

Rotary: 3.5x28

Fill Head: (Several Pieces)

Nozzle: 3x18

Plunger: 3x12

Shaft: 3x5.5

Upper, Outer: 2x18

Upper, Inner: 2.5x13

Rotary to chamber gasket: 1.5 inch TC (tri-clamp)

Rotary to hopper gasket: 1.5 inch TC (tri-clamp)

Rotary to fill head gasket: .75 inch TC (tri-clamp)

Rotary flange o-rings: 2x28


Rotary bearings: 2x28


Nozzle: 10x30

***Machine must be cleaned, sanitized, and lubricated with H3 food grade lubricant prior to use. A recommended lubricant has been provided.**




4-2 Seal Breakdown









Rotary core in home position, the core arm/clevis will be facing up and in the forward most position



Rotary core in run position, the core arm/ clevis will be facing up and in the rearer most position







Two arrows below point to the orings on the main product piston that is housed inside of the steel product cylinder

