



How To Start The Siphon

To start the flow in the spout, the siphon starter is slipped over the outer tube of the spout and pressed firmly against the weighted drop (bottle stop) on the spout so that the gasket on the starter forms a seal; the stop, in turn, should slide up until it is in contact with the gasket located immediately under the junction of the gooseneck and inner tube. While keeping the starter pressed against the bottle stop the bulb should be compressed and released by hand several times until liquid is drawn from the tube filling both the filling spout and the bulb. With the bulb full, the starter is withdrawn from the nozzle, permitting the outer tube to slide down thereby retaining the liquid in the spout. This same operation is repeated with each of the spouts after which it is not necessary to use the starter bulb again during the filling operation.



Cleveland Equipment

866-888-6327

www.clevelandequipment.com